

# METRIC FITMENT CHART 5/20/2011

<u>Make</u>	<u>Model</u>	<u>Year</u>	<u>Recommended Kit</u>	<u>Comments</u>	<u>Bar Weights</u>
Honda	Silver Wing 600	2008-2010	211126/211125	Use Goldwing kit	
Honda	NTV 700	2010	211076/211075	Has bar end weights	
Honda	Shadow 750-all	2009-2011	211065/211066		
Honda	VFR1200	2010	211076/211075	Mount only on handlebar close to handlebar top clamp	Y
Honda	ST1100/ST1300	2000-2011	211126/211125	Use Goldwing kit	
Honda	VT1300 Interstate	2010-2011	210019	Needs 1" spacer (Has Fat Bars)	Y
Honda	Fury 1300	2010-2011	210019	Needs 1" spacer (Has Fat Bars)	
Honda	Sabre 1300	2010-2011	210019	Needs 1" spacer (Has Fat Bars)	
Honda	Valkyrie 1500	1997-2003	211065/211066		
Honda	Goldwing 1200/1500/1800	ALL	211126/211125		Y
Kawasaki	Ninja 250/500	2008-2011	211125/211126	Use Gold Wing kit . Mount on Right side only	Y
Kawasaki	Vulcan 500	2009-2011	211075/211076	Use stand alone clamp only, stock clamp has mirror mount	Y
Kawasaki	ZX6R Ninja	2009-2001	210019		
Kawasaki	ER6N	2009-2011	211125/211126	Use Goldwing kit	Y
Kawasaki	KLR650	2010-2011	211075/211076		
Kawasaki	KLE650/Versys	2009-2011	211075/211076	Use stand alone clamp only, stock clamp has mirror mount	Y
Kawasaki	Ninja 650	2009-2011	211075/211076	Right Side mount	Y
Kawasaki	VN 900 LT/Custom	2010-2011	211075/211076	Use stand alone clamp only, stock clamp has mirror mount	Y
Kawasaki	Z1000	2010-2011	211075/211076		Y
Kawasaki	ZX1000	2011	211125/211126	Use Goldwing kit	Y
Kawasaki	ZX10-R	2011	210019		
Kawasaki	ZX1400/ Concours 1400	2009-2011	211126/211125	Use Goldwing kit	Y
Kawasaki	VN1700 Classic	2009-2011	211075/211076	Use stand alone clamp only, stock clamp has mirror mount	Y
Kawasaki	Voager 1700	2009-2011	210019	Has fat bars with plugs and off-set bolt pattern on perch	Y
Kawasaki	Vulcan Vaquero 1700	2011	210019	Has fat bars with plugs	
Kawasaki	Nomad 1700	2010-2011	211075/211076	Use stand alone clamp only, stock clamp has mirror mount	Y
Kawasaki	Vulcan 2000	2009-2010	211075/211076	Use stand alone clamp only, stock clamp has mirror mount	Y
Yamaha	R6/R1	All	210019		
Yamaha	FZ6/FZ8/FZ-1	ALL	211075/211076	Right side mount to reservoir	Y
Yamaha	T-Max	2009-2011	210019		
Yamaha	650 V-Star ALL	2006-2011	211075/211076	Right side mount to reservoir	Y
Yamaha	950 V-Star All	2010-2011	211075/211076	Right side mount to reservoir	Y
Yamaha	1300 V-Star All	2009-2011	211075/211076	Right side mount to reservoir	Y
Yamaha	1300 Royal Star	All	211075/211076	Right side mount to reservoir	Y
Yamaha	V-Max	2011	211075/211076	Use stand alone clamp only. Has ALuminum bars	Y
Yamaha	FJR1300	2008-2011	211125/211126	Use Goldwing kit	Y
Yamaha	1300 Styker	2011	211075/211076	Right side mount to reservoir	Y
Yamaha	1700 Warrior	2009	211075/211076	Right side mount to reservoir	Y
Yamaha	1700 Road Star	2009-2010	211075/211076	Right side mount to reservoir	Y
Yamaha	1900 Raider	2009-2011	211075/211076	Must mount controller close to top handlebar clamp	Y
Yamaha	1900 Roadliner/Stratoliner	2006-2011	210019	Has 1 1/4" bars, clamps like Victory	Y
Suzuki	Burgman 400/650	2008-2011	210019		
Suzuki	DRZ400/650	All	211075/211076		Y
Suzuki	GS500-F	All	211075/211076	Right side mount to reservoir	Y
Suzuki	GSXR 600/750/1000	All	210019		
Suzuki	GSX1200/1250 Bandit	All	211075/211076	Could use Internal kit if bar end weights are removed	Y
Suzuki	DL650/1000 V-Strom	2007-2011	211075/211076	Could use Internal kit if bar end weights are removed	Y
Suzuki	SV650/1000/S	All	211075/211076	Right side mount to reservoir	Y
Suzuki	S40/Savage 650	2009-2011	211065/211066	Must use stand alone clamp	
Suzuki	M50/VZ800	2009-2011	211075/211076	Right side mount to reservoir	Y
Suzuki	C50T/800 Voulisia	2009-2011	211075/211076	Right side mount to reservoir	Y
Suzuki	S50/VS800 Intruder	2009-2011	211075/211076	Could use Internal kit if bar end weights are removed	Y
Suzuki	VL800	2009-2011	211075/211076	Could use Internal kit if bar end weights are removed	Y
Suzuki	S83/VS1400 Intruder	2009-2011	211075/211076	Could use Internal kit if bar end weights are removed	Y
Suzuki	M90/VZ1500 Intruder	All	211075/211076	Could use Internal kit if bar end weights are removed	Y
Suzuki	C90T/1500 Volusia	2009-2011	211075/211076	Could use Internal kit if bar end weights are removed	Y
Suzuki	C109/VLR1800	2009-2011	211075/211076		Y
Suzuki	M109R/VZR1800	2007-2011	211075/211076	Right side mount to reservoir	Y
Triumph	Sprint	All	211125/211126	Use Goldwing kit	Y
Victory	Models with 1" handlebars	All	211065/211066	Must use stand alone clamp	
	Models with 1-1/4" handlebars	All	210019		