

# **Heated Grip/POCO Installation Failure Instructions**

## **What to do in the event the grip stops half way on**

All is not lost, **DO NOT CUT OFF.** The stuck grip **CAN BE REMOVED.** To do this the grip needs to be heated up using the internal heater in the grip. For the clutch side connect the two wires to a battery. For the throttle side use the controller to energize the heater. To do this, plug the two halves of the white connector together and then connect the two wires of the controller to the battery. Remember red wire to the positive side of the battery. With the controller set the grip control to the fifth LED. Warm the grip to the point where it is hot to the hand. With a twist and a pull the grip will come off.

**DO NOT LEAVE GRIP UNATTENDED!!!** The heater will burn itself out if allowed to get too hot, as there is no heat sinking going on.

With the grip removed go back to the start of installation. Use the two step procedure with the WD-40, ie. saturate once, let rest for 10 minutes, saturate again and also spray the bar, then slip on the grip.

The reheat will not work after 24 hours on the handle bar.

**If additional customer service support is needed, please call 763-571-9193.**